

# bugaboo frog instructions for use

## **Dear Parents and other users,**

Congratulations on your purchase of this Bugaboo Frog. We took great care to make it safe, comfortable and easy to use; please read these instructions carefully before you use it the first time. We would love to hear your comments on its design, use, instructions or anything else you feel would improve it. Also, Bugaboo Customer Service at [service@bugaboo.us](mailto:service@bugaboo.us) can answer questions about your new Bugaboo Frog.

## important information

This user guide is only valid for Bugaboo Frogs with Item Code 38022201, which can be found on the serial number sticker on the central axle of the undercarriage.

Pram, pushchair, buggy compliant with standard ASTM F833-01.

Your child's safety may be affected if you fail to follow these instructions. Read them carefully before using your Bugaboo Frog and keep them for future reference.

Familiarize yourself with the operation of your Bugaboo Frog before using it.

Never use force on your Bugaboo Frog. If you have problems, recheck the instructions or call Bugaboo Customer Service at 1-310-372-2976.

The brake must only be used as a parking brake.

Always engage the parking brake before you adjust your Bugaboo Frog.

Your Bugaboo Frog is designed to carry one child who weighs less than 40 pounds.

The Bugaboo Frog with bassinet is designed to carry one child who is under 6 months old, who weighs less than 20 pounds, and who is less than 28 inches tall.

The Bugaboo Frog under-carriage bag is NOT designed to transport more than 8 lb.

Total weight suspended from handlebar should never exceed 8 lb.

The Bugaboo Frog is designed to carry only one child.

The Bugaboo Frog is NOT A JOGGER. DO NOT JOG OR RUN with the Bugaboo Frog.

Do not let children play with or near the Bugaboo Frog.

Use the wrist strap attached to the handlebar AT ALL TIMES.

Always remove your child when adjusting positions or configurations of your Bugaboo Frog. Adjusting while the child is in place may cause serious injury.

THE BUGABOO FROG SEAT/BASSINET IS NOT A CAR SEAT. Use an approved car seat when your child travels in a car. Graco and Peg Perego car seats are approved, and are compatible with the Bugaboo Frog chassis using the Bugaboo adaptor\*. See Section L (Optional Accessories).

Remove your child from your Bugaboo Frog before going up or down stairs, escalators or steep slopes.

Lift the front wheels of your Bugaboo Frog to move it up or down curbs.

The crossbars between the wheels are not designed to support weight. Standing on them is unsafe and can damage your Bugaboo Frog.

Keep your Bugaboo Frog away from heat sources or open flame. Be especially careful near burning cigarettes. The fabric used in your Bugaboo Frog meets the flammability requirements of the California Bureau of Home Furnishings Technical Bulletin 117.

Use only the Bugaboo-recommended products and accessories described in Section L (Optional Accessories) with your new Bugaboo stroller.

Extended exposure to sunlight can slightly discolor some parts of your Bugaboo Frog.

Do not expose your Bugaboo Frog to extreme heat or cold.

Your Bugaboo Frog's warranty is voided in the event of damage due to overload, improper folding or use of non-Bugaboo-recommended accessories. See the Warranty Form for more information.

Do not assemble your Bugaboo Frog in the presence of small children.

Check regularly to be sure that all safety devices work properly.

Only use spare parts supplied or approved by Bugaboo.

Bugaboo™ and FROG™ are trademarks of Bugaboo Design & Sales USA, Inc., subject to license. Such marks may not be used without express permission.

The Bugaboo Frog is patented and the design is protected.

\* Graco and Peg Perego are the trademark of Graco and Peg Perego, Inc, and is not associated with Bugaboo Design & Sales USA, Inc. No approval or endorsement by them is to be implied.

- ⚠ WARNING** Do not use your Bugaboo Frog if any part is broken, cracked, incomplete or worn out.
- ⚠ WARNING** Never leave any child unattended.
- ⚠ WARNING** Infants and young children can suffocate and die if their faces are in or next to a plastic bag. Discard this bag immediately. Keep this bag away from children, infants, cribs, beds, playpens or carriages.
- ⚠ WARNING** Any load attached to the handlebar will affect the stability of the stroller and may cause tipping or loss of control.
- ⚠ WARNING** Wear wrist loop at all times
- ⚠ WARNING** Do not run, jog or skate with the Bugaboo Frog
- ⚠ WARNING** When the seat / bassinet frame / car seat adaptors are properly attached to the Bugaboo Frog chassis it prevents the undercarriage from folding.
- ⚠ WARNING** Bags and other items should never be suspended from the Bugaboo Frog handle bar by any means other than the Bugaboo diaper bag, the Bugaboo bag clips and the Bugaboo parasol, because the stroller could become unstable. Please refer to corresponding user guides before these Bugaboo products.
- ⚠ WARNING** Audible 'click' must be heard in order to determine that each lock is in proper position. To ensure proper locking engagement, check to see that the seat / bassinet / car seat adaptors / carry handle cannot be disengaged from the stroller without unlocking the device. Failure to attach properly could result in serious injury or death to your child.
- ⚠ WARNING** Always remove child from the seat / car seat / bassinet before making adjustments to stroller.
- ⚠ WARNING** Suspending more than 3.6 kg/8 lbs from the handle bar could cause your Bugaboo Frog to tip over and seriously injure your child, especially when the stroller is used on grades or inclines. Suspending more than 2.5 kg/5.5 lbs is not recommended.
- ⚠ WARNING** Care must be taken when folding and unfolding the product to prevent finger entrapment.
- ⚠ WARNING** The product will become unstable if a parcel bag or rack is used when there is no provision for one.
- ⚠ WARNING** The product will become unstable if the manufacturer's recommended load is exceeded.

# preparing and using your bugaboo frog

Follow these instructions carefully and observe the sequence of the diagrams and text. The letters and numbers of the diagrams and text correspond.

**⚠ WARNING** Failure to follow these instructions may result in death, serious injury or harm to your child.

**⚠ WARNING** Always remove your child from the seat and/or bassinet before you adjust it. Never lift, reverse or carry your Bugaboo Frog with a child in the seat.

**⚠ WARNING** The brake is for parking only. The brake lever must be in its lowest position to lock. Use it only when your Bugaboo Frog is completely stopped, and any time you adjust your Bugaboo Frog.

**⚠ WARNING** All babies have highly sensitive skin. NEVER leave a baby unprotected in the sun! Use the Sun Canopy or Bugaboo Parasol shown in Section L (Optional Accessories).

---

## **A** to fit the wheels to the chassis

### **Fitting the wheels**

- 1 Place the chassis as shown with the plastic parts on the ground.
  - 2 Slide swiveling wheel blocker upwards.
  - 3 Push the swivel hubs into the sockets as shown until you hear a click from each one. Be careful not to put the swivel hubs into the wrong end of the sockets. Now push the large wheels with pneumatic tires into the sockets as shown until you hear a click from each one.
- 

**⚠ WARNING** Ensure that the valve caps and nuts are firmly tightened so children cannot swallow them.

**⚠ WARNING** Do not put the swivel hubs into the wrong end of the sockets.

---

## **B** to unfold the chassis and attach the bag

### **Unfolding the chassis**

- 1 To unlock the handlebar, pull the two release knobs towards you and lift. Do not press on the handlebar while pulling the knobs.
  - 2 Release the knobs and raise the handlebar to the position shown in Diagram B until you hear a click on each side.
  - 3 Place your foot on the crossbar between the swivel hubs and gently push the crossbar away from you while raising the handlebar.
  - 4 Place the chassis on all four wheels and pull the swivel hub locking switch down.
- 

### **Attaching the Bugaboo Frog Bag**

- 5 Attach the luggage bag to the undercarriage by fastening the 4 hook & loop fasteners on the aluminum frame. The bag may remain in place when the undercarriage is folded.
-

**⚠ WARNING** The Bugaboo Frog underseat bag is designed to carry a maximum of 8 lbs.

**⚠ WARNING** Pneumatic tires and spring swivel hubs provide cushioning. Do not inflate them above 15 PSI / 1 bar.

**⚠ WARNING** Ensure that all locking devices are engaged before you use your Bugaboo Frog.

---

## **C** to prepare your bugaboo frog bassinet

The bassinet is a freestanding unit that can be used without the frame. To prepare it for use, fit the bassinet liner to the seat/bassinet frame. The liner is supplied complete with mattress and apron. The seat cover can also be fitted to the seat/bassinet frame, but you must remove the seat cover to use the bassinet. To do this, carry out the instructions in Diagram E in reverse order. THIS BASSINET IS NOT A CAR SEAT. Children must ride in an approved car seat while traveling in a car.

### **Fitting the bassinet liner to the seat/bassinet frame**

- 1 The bassinet upholstery is fastened to the seat/bassinet frame with hook & loop fasteners. Ensure that the round side of the bottom plate of the bassinet upholstery corresponds to the round side of the seat/bassinet frame. The numerical order shows you how to attach the bassinet upholstery. First position the plastic slots (No. 1) in the pocket. Then attach the hook & loop fasteners (No. 2-7). Make sure to observe the numerical order of the hook & loop fasteners. Attach the hook & loop fasteners at the lower end of the sides of the bassinet upholstery tightly to the side supports of the seat/bassinet frame.

### **Attaching the sun canopy**

- 2 Attach the supplied sun canopy with stiffeners and fabric by clicking the two clips onto the seat/bassinet frame.

### **Attaching the carry handle**

- 3 Attach the carry handle by pressing the small square buttons and sliding the ends into the slots until you hear a click on each side. Always check to ensure that the carry handle is fitted correctly before you use it to lift the bassinet.

### **Removing the carry handle**

- 4 To remove the carry handle, press the small square buttons firmly and pull the ends out of the slots.

### **Fitting the apron**

- 5 The apron can be attached to the bassinet to protect your child against wind and weather. Fit it to the foot end of the seat/bassinet frame by hooking the elastic bands at the ends of the cover to the hooks on the canopy clips.

**⚠ WARNING** Do not add a mattress thicker than 1.2 inches.

**⚠ WARNING** Never put the seat/bassinet in a high place such as a table, bed, etc.

**⚠ WARNING** Always keep the bassinet horizontal when in use.

**⚠ WARNING** Always check to ensure that the carry handle is fitted correctly before you use it to lift the bassinet. Failure to do so could cause harm, serious injury or death to child.

## **D** to use the bassinet freestanding and on the chassis

### **Using the bassinet**

The bassinet is designed for infants who are younger than 6 months, who weigh less than 19 pounds, and/or who are shorter than 28 inches. It is designed solely for infants who cannot sit up and/or push themselves up using their hands and/or knees. In the bassinet your baby can lie completely flat, taking the load off the spine completely and allowing your baby to stretch its legs. The bassinet is a freestanding unit and can be used as a bassinet on the Bugaboo Frog chassis.

### **Attaching the bassinet to the chassis**

- 1 Slide the side brackets of the bassinet onto the legs sticking up from the chassis until you hear a click on each side.

### **Removing the bassinet from the chassis**

- 2 Press the large white square buttons on both sides of the bassinet at the same time, then lift it by the carry handle.

### **Reversing the bassinet**

- 3 The bassinet can be fitted to the chassis facing either way. To change the direction, remove it, turn it around and reinstall it.

**⚠ WARNING** Ensure that all locking devices are engaged before use.

**⚠ WARNING** Always use the bassinet on a horizontal, firm, flat surface, whether or not it is attached to the Bugaboo Frog.

**⚠ WARNING** Keep the bassinet horizontal at all times when in use.

**⚠ WARNING** Always remove your child before adjusting the seat/bassinet.

**⚠ WARNING** Before lifting the bassinet by the carry handle always check that the carry handle is fitted correctly. Failure to do so could cause harm, serious injury or death to your child.

**⚠ WARNING** Read parts G & H of these instructions before using the bassinet with the Bugaboo Frog chassis.

**⚠ WARNING** To avoid serious injury or death to child do not use this bassinet as a car bed.

**⚠ WARNING** Audible 'click' must be heard in order to determine that each lock is in proper position. To ensure proper locking engagement, check to see that the seat / bassinet / car seat adaptors / carry handle cannot be disengaged from the stroller without unlocking the device

## **E** to prepare your bugaboo frog seat

Prepare your Bugaboo Frog seat by attaching the seat cover and the carry handle to the seat/bassinet frame. The seat/bassinet frame can also be used with the bassinet liner, but the bassinet liner must be removed before you can use it as a seat. To do this, carry out the instructions in Section C in reverse order.

### **Fitting the seat cover to the seat/bassinet frame**

- 1 Stand the seat/bassinet frame as shown in Diagram C.
- 2 Slide the sleeve of the seat cover over the top of the seat/bassinet frame with the Bugaboo logo at the front. Ensure that the rounded top of the sleeve is at the rounded end of the seat/bassinet frame. Pull the sleeve down tightly. Fasten the sleeve of the backrest at the bottom and sides with the hook & loop fas-

teners. Fold the seat portion inwards to convert the unit into a seat.

- 3 Position the O-ring over the projecting pin (see red arrow A). This is easiest when the carry handle is not connected, as the frame can flex slightly. Then position the seat onto the side. Bend the seat/bassinet frame inwards by pushing on the side of the seat/bassinet frame (see red arrow B). Pull the ties and position the O-ring over the projecting pin (see red arrow C).
- 4 Click the ties together under the seat (see red arrow A). Fasten the two hook & loop fastener strips at the foot to the underside of the seat/bassinet frame (see red arrow B). Ensure that the hook & loop fasteners and the ties are properly fastened. Then slip the waist straps through the appropriate holes in the sides of the seat cover (see red arrow C).

#### **Attaching the sun canopy**

The sun canopy attaches to the seat and to the bassinet in the same way. See Diagram C2.

#### **Attaching the carry handle**

- 5 Attach the carry handle to the seat by pressing the small white square buttons and sliding the ends into the slots until you hear a click on each side.

#### **Removing the carry handle**

- 6 Push down slightly on the carry handle, then press the small square buttons firmly and slide the ends of the carry handle out of the slots.

**⚠ WARNING** Always check to ensure that the carry handle is fitted correctly before you use it to lift the bassinet.

**⚠ WARNING** Avoid serious injury from falling or sliding out. The occupant restraint system is to be used.

**⚠ WARNING** When locking the carry handle, you must hear a click on each side. Failure to properly attach the carrying handle could result in the serious injury or death of your child.

## **F** to use the seat freestanding and on the chassis

Your Bugaboo Frog seat is designed to carry one child who weighs less than 37 pounds. When using your Bugaboo Frog freestanding, put the backrest in the semi-reclining position. When using the seat on the chassis, the backrest can be adjusted to sitting, semi-reclining and reclining positions, and the angle between the backrest and the seat of your Bugaboo Frog seat unit will remain constant. With infants younger than six months, do not use the seat in the sitting position. Use it only in the reclining and semi-reclining position, and then for not more than two hours at a time.

#### **Seat used freestanding with backrest in semi-reclining position**

- 1 The seat can only be placed freestanding on the ground when the backrest is in the semi-reclining position. To set this position, open out the seat adaptors completely backwards.

#### **Attaching the seat to the chassis**

Slide the side brackets of the seat onto the lugs sticking up from the chassis until you hear a click on both sides, in the same way as with the bassinet. See Diagram D1.

#### **Changing the position of the seat after attaching it to the chassis**

- 2 To change position, press the round buttons on the side brackets and tilt the seat as desired.

#### **Removing the seat from the chassis**

To remove the seat from the chassis, press the large white square buttons on each side of the seat at the same time, then lift it by the carry handle. See Diagram D2.

#### **Reversing the seat**

The seat will fit the chassis facing either way. To reverse it, remove it from the chassis, turn it around, and reinsert it until you hear a click on both sides. (See Diagrams D3 and D4.) The sitting, reclining and semi-reclining positions can be set with the seat facing either way.

### Using the seat harness

- 3 Always use the five-point harness to secure your child in the Bugaboo Frog seat. The shoulder straps, crotch strap and waist straps are already fitted. Position the waist straps as shown in Diagram E3, then place your child in the Bugaboo Frog seat. Pull the crotch strap out between your child's legs. Pull the shoulder straps over your child's shoulders and attach them to the crotch strap. Pull the waist straps across your child's waist and attach them to the crotch strap. You should hear a click each time you attach a strap to the crotch strap. Tug on each strap to ensure it is firmly attached.
- 4 Your child is now secured in your Bugaboo Frog seat. If your child tends to slip down, pull the crotch strap through the black loop on the seat before attaching the shoulder and waist straps.

#### **WARNING**

Your child may fall backward if the seat adaptors are not pulled straight backward for support when the seat is used separately.

#### **WARNING**

Always use the crotch strap and the waist belt to avoid serious injury from falling or sliding.

#### **WARNING**

Ensure that all locking devices are engaged before use.

#### **WARNING**

Always check to ensure that the carry handle is fitted correctly before you use it to lift the seat.

#### **WARNING**

Always use the crotch strap AND the waist belt.

#### **WARNING**

Use the five-point harness as soon as your child can sit unaided.

#### **WARNING**

Don't let your child surprise you with unexpected movements: ALWAYS use the harness.

#### **WARNING**

The harness must be adjusted to fit your child and properly fastened.

#### **WARNING**

If your child tends to slip down, pull the crotch strap through the black loop on the seat before attaching the shoulder and waist straps.

#### **WARNING**

Read Sections G and H of these instructions before using the seat with the Bugaboo Frog chassis for the first time.

#### **WARNING**

Audible 'click' must be heard in order to determine that each lock is in proper position. To ensure proper locking engagement, check to see that the seat / bassinet / car seat adaptors / carry handle cannot be disengaged from the stroller without unlocking the device

## to use the swivel hub lock/brake and parking brake

### Swivel hub lock/brake

- 1 To keep the wheels from swiveling, raise the white locking switch on the swivel hubs until it fits into the black holder.
- 2 For best maneuverability, slide the white locking switch fully downward so the small wheels can swivel.

### Operating the parking brake.

- 3 Your Bugaboo Frog parking brake acts on the rims of the large wheels and is operated by a lever on the handlebar. To engage the parking brake, push the lever to its lowest position.
- 4 To disengage the parking brake, push the white button on the lever. The lever will spring back.
- 5 Use the brake cable spanner to adjust the brake cable. Screwing the nut upwards loosens the cable; screwing it downwards tightens it.

### **WARNING**

Ensure that your Bugaboo Frog parking brake is properly engaged.

### **WARNING**

Always apply the parking brake when parking or adjusting your Bugaboo Frog.

### **WARNING**

Brake is parking brake only. To be used only when completely stopped. Brake must be in furthest downward position to be locked.

## to use your bugaboo frog in town, in the woods and on the beach

Read the following diagrams and text in sequence to best understand the various ways of using your Bugaboo Frog in town, in the woods and on the beach.

### Using the Bugaboo Frog in town (four-wheel position)

- 1 When using your Bugaboo Frog in town, place the handlebar over the large wheels and unlock the swivel hubs. (See Diagram G2.) This gives your Bugaboo Frog maximum maneuverability and lets you negotiate pavement with ease. To move the handlebar over the large wheels, pull the two release knobs on the inside of it towards you, then pull the handlebar across. Do not exert force on the handlebar while pulling the knobs.

### Using the Bugaboo Frog off-road (four-wheel position)

- 2 When using your Bugaboo Frog in the woods or on bumpy surfaces, place the handlebar over the swivel hubs. This puts the large wheels in front to let you negotiate bumps with ease. Lock the swivel hubs by fully raising the locking switch. (See Diagram G1.) To move the handlebar over the swivel hubs, pull the two release knobs on the inside of it towards you, then pull the handlebar across. (See Diagram H1.) Do not exert force on the handlebar while pulling the knobs.

### Using the Bugaboo Frog on the beach or other difficult terrain (two-wheel position)

- 3 When using your Bugaboo Frog on a level beach, place the chassis in the two-wheel drive position. To do this, remove the seat from the chassis, lock the swivel hubs and put the handlebar over the swivel hubs.
- 4 Once you have pulled the handlebar over, push the crossbar between the swivel hubs down until you hear a click.
- 5 You can now put the seat on the chassis in the two-wheel position.
- 6 When the buggy is in the two-wheel position, the seat can only face the direction of travel.
- 7 Lateral stability is substantially reduced in the two-wheel position. Take care not to let your Bugaboo Frog fall over when using it this way on rough terrain.

### **WARNING**

Ensure that all locking devices are engaged before use.

### **WARNING**

Remember that the seat is not reversible in the two-wheel position. It can only face in the direction of travel.

### **WARNING**

Do not use two-wheel position with the bassinet or car seat, as the child cannot be secured to it with the harness.



## **⚠ WARNING**

Your Bugaboo Frog is much less stable in the two-wheel mode. You must take extra care that it does not tip over sideways. Your Bugaboo Frog is safe only on a level surface. Ignoring this warning could result in loss of control and tipping of stroller, and death or serious injury to your child.

## **⚠ WARNING**

Use the wrist strap attached to the handlebar at all times.

## **⚠ WARNING**

Always pull Your Bugaboo Frog in the two-wheel mode; pushing may tip it over.

## **⚠ WARNING**

The swivel hubs of your Bugaboo Frog will become extremely dirty on the beach. Remove them when using the buggy in the two-wheel drive position.

## **⚠ WARNING**

The Bugaboo Frog is not saltwater-resistant.

## **⚠ WARNING**

The two-wheel position of the Bugaboo Frog chassis is to be used on horizontal surfaces only. Ignoring warning could result in loss of control or tipping and death or harm to your child.

---

# **I** to collapse the bugaboo frog and remove the wheels

### **Removing the seat/bassinet from the chassis**

Before collapsing your Bugaboo Frog, you must remove the seat/bassinet from the chassis. (See Diagram D2.)

### **Folding the chassis in two-wheel drive position**

Set the chassis to two-wheel drive. (See Diagrams H3 and H4.) You can now put the chassis away or simply hang it from the handlebar.

### **Fully collapsing the chassis with wheels**

- 1 Place the Bugaboo Frog chassis in the four-wheel drive position with the handlebar over the large wheels. Lock the swivel hubs. Move the handlebar down by pulling the two release knobs on the inside of it towards you.
- 2 Lift the Bugaboo Frog chassis by the central crossbar and fold the wheels together until you hear a click.
- 3 Your fully collapsed Bugaboo Frog should look like Diagram I3.

### **Fully collapsing the chassis without wheels**

- 4 Remove the swivel hubs from their sockets by holding in the two plastic spring clips and pulling the whole unit out of the socket.
- 5 Remove the large wheels by squeezing the ends of the metal spring clip together and pulling the wheel out of the socket.

### **Collapsing the seat/bassinet**

To make the seat totally flat, fold the side supports completely against the seat/bassinet frame. (See Figure F1.) Then lift the seat bottom (See Figure E2.) and disassemble the carry handle (See Figure E5.).

To make the bassinet totally flat, detach the hook & loop fastener straps at the foot and head of the bassinet (See Figure C1 No. 2.) and remove the plastic slats (See Figure C1 No. 1.). Then fold the side supports completely against the seat/bassinet frame (See Figure F1.) and dismount the carry handle (See Figure C4.).

## **J** maintenance

### General points

Regularly check whether all safety devices are working correctly.

Regularly check the carry handle and the base of the seat or bassinet for damage.

Only use spare parts supplied or approved by Bugaboo.

Folding up the Bugaboo Frog or accessories while still wet or storing them in a damp place can cause mildew.

If the inner tubes of the large wheels develop leaks you can repair them in the same way as a bicycle inner tube. Well-stocked bicycle shops sell new inner tubes and tires of the correct size.

### Cleaning

Clean your Bugaboo Frog with a damp cloth and a mild detergent.

The swivel hubs are particularly susceptible to dirt. Clean them regularly by removing them as described above, rinsing them in lukewarm water, then lubricate them with silicone or Teflon spray and reinstall them.

The wheel bearings must not be lubricated.

All Bugaboo Frog covers and liners are removable and MACHINE-washable at max. (30C). Do not bleach, iron, dry-clean or tumble-dry liners or covers. ALWAYS remove stiffeners and removable foam parts before washing.



## **⚠** WARNING

Always observe the washing instructions.

## accessories

## **K** accessories supplied as standard

### Bugaboo Frog Under Seat Bag

The Bugaboo Frog under seat bag designed to carry a maximum of 8 pounds. For fitting, see Diagram B5.

### Sun Canopy

All babies have highly sensitive skin. NEVER leave a baby unprotected in the sun! Use the Sun Canopy or Bugaboo Parasol shown in Section L (Optional Accessories).

### Mosquito Net

The mosquito net keeps flies, mosquitoes and other insects away from your child. Attach it to the foot end of the seat/bassinet over the sun canopy.

### Rain Cover

The rain cover protects your child from rain and wind. Attach it to the foot end of the seat/bassinet frame over the sun canopy. Remove the textile from the sun canopy to give your child an unobstructed view. The rain cover has a prefixed rib; slide the holes on either end of it across the pins sticking out on the side of the seat/bassinet frame. At the front of the rain cover is an air vent; for optimal ventilation ensure that the hook & loop fastener strips of the air vent meet well when pressed together.

## **⚠** WARNING

Under direct sunlight, temperatures under the sun canopy can become uncomfortably warm.

## **⚠** WARNING

To avoid uncomfortable heat build-up, lower the rain cover when the rain stops.

## **⚠** WARNING

Ensure optimum ventilation by firmly pressing the hook & loop fasteners of the rain cover air vent together.

## **L** optional accessories

Parasol

A wheeled board enabling you to transport a second toddler

Footmuff

Car Seat Adaptor

Diaper Bag

Transport Bag

Bag Clips

### **⚠ WARNING**

Suspending more than 3.6 kg/8 lbs from the handle bar could cause your Bugaboo Frog to tip over and seriously injure your child, especially when the stroller is used on grades or inclines. Suspending more than 2.5 kg/5.5 lbs is not recommended.

## warranty

### **Terms of Warranty**

- 1 These terms apply to all pushchairs manufactured by Bugaboo, unless otherwise agreed with the supplier.
- 2 The warranty commences on the date of purchase and is valid for a period of twentyfour months.
- 3 In the event of defects the owner should contact the supplier.
- 4 If the supplier is unable to remedy the problem he shall send the product to the manufacturer with a clear description of the problem and a copy of the dated purchase receipt. In the case of repairs under the terms of the warranty, transport is at the manufacturer's cost and risk.
- 5 The manufacturer is under no obligation to replace or take back the product.
- 6 The warranty applies solely to products to which the user has not made any modifications.
- 7 The warranty is valid for the first owner only and is not transferable.
- 8 Repairs do not entail any right to an extension of the warranty period.
- 9 Bugaboo accepts no liability whatsoever for damage other than to the product manufactured by Bugaboo.

### **The warranty is invalid if**

- 1 The warranty card has not been correctly completed and returned to Bugaboo.
- 2 The product is not offered to the manufacturer with the purchase receipt and warranty card.
- 3 Defects are due to incorrect use or maintenance contrary to the instructions.
- 4 Repairs to the product have been effected by a third party without the manufacturer's prior consent.
- 5 The defect is due to neglect or the result of an accident.
- 6 The serial number is found to have been damaged or removed.
- 7 There is wear and tear due to daily use of the product.
- 8 The terms of the warranty have not been observed.
- 9 purchased from any and all unauthorized retailers or sellers

## important

The warranty period for the Bugaboo stroller is two years from the date of purchase. The warranty is only valid if you complete the warranty form and send it to Bugaboo. You should also make a note of the BUGABOO FROG serial number on this warranty: you will find it on the outside of the frame just above the large wheels. Keep the warranty and purchase receipt in a safe place.

Unless otherwise specified on the warranty card, the information you supply will also be used to keep you informed of special offers on Bugaboo products.