

# Model Hola Stroller

## Features:

- **Bassinet and Stroller Seat all in one.** - No need for separate items as your child grows. Smart conversion seat which can be easily used in a Bassinet or Seat configuration.
- Lightweight aluminium frame.
- Reversible seat.
- Adjustable handle height.
- Single action locking front swivel wheels.
- Independent front wheel suspension.
- Easy to manoeuvre.
- Pneumatic tyres.
- Can be folded with bassinet / seat (mother behind baby mode).
- Comes complete with semi raincover, sunshade and bootcover.
- Complies with the Australian Standard AS/NZS 2088:2000

**Additional products and accessories are available from leading department stores and nursery speciality shops include:-**

Portable Cots, Change Tables, Highchairs, Hook on Highchairs, Safety Gates, Bed Guards, Rockers, Parasoles, Pramettes, Strollers, Walkers, Nappy Bags, Rain Covers, Wooden Cots and Manchester.

## Warranty

The manufacturer warrants this product to be free from defects in material and workmanship under normal use and service following the date of purchase for 12 months. This warranty shall not apply to damages arising from neglect, accidental damage to, or misuse of the product.

**Due to our continuing programme of development, Childcare reserves the right to alter the specifications, colour or design without further notice.**

**Due to variations in the style and design of our products the illustrations used in this instruction manual are generic.**

This product is not intended for commercial use.



CNP Brands  
20 Calarco Drive, Derrimut, VIC, 3030  
Customer Service Number: 1300 667 137  
e-mail: [info@cnpbrands.com.au](mailto:info@cnpbrands.com.au)  
[www.cnpbrands.com.au](http://www.cnpbrands.com.au)

# Hola Stroller 015410

Line Drawings to be  
inserted by Factory



Keep this booklet in a safe place for future reference  
Note: Colour and features of product may differ from the diagrams shown  
[www.childcareproducts.com.au](http://www.childcareproducts.com.au)

### **WARNING**

- FOLLOW THE MANUFACTURER'S INSTRUCTIONS.
- PUT ON ALL THE BRAKES WHENEVER YOU PARK THE STROLLER.
- DO NOT LEAVE CHILDREN UNATTENDED.
- DO NOT CARRY EXTRA CHILDREN OR BAGS ON THIS STROLLER.
- MAKE SURE CHILDREN ARE CLEAR OF ANY MOVING PARTS IF YOU ADJUST THE STROLLER OTHERWISE THEY MAY BE INJURED.

### **Some Do's and Don'ts**

- Check that all safety locks are engaged before placing a child in the stroller.
- Ensure your child is secured with a correctly adjusted safety harness.
- Do not allow children to stand on the seat.
- Do not hang bags or goods from the handle as this could cause the stroller to tip over.
- Do not place more than 3kgs in the basket, or 1kg in the canopy pocket (if supplied).
- The weight of the child using this stroller alone should not exceed 17kg.
- The height of the child using the stroller should not exceed 96cm.
- The bassinet should not be used once the child can sit up unaided.
- Do not use accessories other than those supplied and approved by Childcare Nursery Products.
- Never ride with more than one child in the stroller.
- Promptly replace worn out or broken parts.
- Always use the safety locks.
- Remove the child from stroller/pram before going up or down stairs and escalators.
- Do not lift stroller by the bumper bar or tray (if supplied).
- To prevent the risk of the stroller catching fire, do not park it near an open fire or a heater.
- Retain your warranty card and keep your sales receipt to provide proof of purchase.
- Recommended tyre pressure: 20-25 PSI.

## **How to Care for your Childcare Stroller**

### **Care and Maintenance**

To prolong the life of your nursery product, keep it clean and do not leave in direct sunlight for extended periods of time.

Removable fabric covers and trims may be cleaned using warm water and a household soap or mild detergent. Allow it to dry fully, preferably away from direct sunlight.

### **Helpful Hints**

If the wheels squeak –use a silicon-based spray ensuring it penetrates the wheel and axle assembly.

When using the stroller at the beach – completely clean your stroller afterwards to remove the sand and salt from the mechanisms and wheel assemblies. Dry thoroughly and lubricate with a silicon-based spray.

### **Do Not Dry Clean or Bleach your Fabrics.**

Do not machine wash, tumble or spin dry your fabrics, unless the care labelling on the product permits these methods.

Non-removable fabrics covers and trims may be cleaned using a damp sponge with soap or mild detergent. Allow it to dry completely before folding or storing it away.


In some climates, the covers and trims may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if it is damp or wet. Always store the product in a well-ventilated area.

Always check parts regularly for tightness of screws, nuts and other fasteners – tighten or replace if required. To maintain the safety of your nursery product, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories approved by Childcare Nursery Products.

This product is not intended for commercial use.

## Restraints

To secure the child in the harness, push buckle **A** and **B** into the buckle housing **C** until the buckle prongs snap into position. Carefully adjust the waist harness by pulling the slider **D** until the desired length is achieved. Follow the same procedure to adjust the shoulder strap. To release the buckles, squeeze the top and bottom prongs until the buckle disengages. Always adjust the harness when changing seating positions.




**Warning:** Many unrestrained children suffer injuries falling from strollers. Use the safety harness at all times.

## Swivel Wheels

To engage swivel lock

- Push swivel lock down.



To disengage swivel lock

- Pull swivel lock up.

Unlocked



## Brakes

To engage brake

- Push brake down.



To disengage brake

- Push brake up.



## Adjustable Handle

- To adjust the height of the handlebar, press both adjustment buttons on handlebar and move handlebar to desired position.



## Open stroller

- Release folding lock as indicated.
- Lift handle, whilst pressing down on rear of the pram, until the frame clicks and locks on both sides.
- Ensure the stroller is locked in on both sides before using.



## Rear Wheel Assembly

- Whilst pressing down on the axle button, place the axles into the holes on the rear of chassis until they click into position.
- Ensure that they are securely fitted by pulling firmly on the wheel.



## Front Wheel Assembly

- Match the front forks with the corresponding red and blue stickers.
- Push the swivel wheel pins into the front frame, Make sure the locking button is engaged and the wheels are securely fitted.



## BASSINET MODE- MOTHER FACING BABY



Recommended for newborn to approximately 6 months of age

### To Assemble Bassinet

- Turn bassinet upside down, lift rear bar.
- Wrap studded fabric around bar and secure with studs.



### To Attach Bassinet onto Stroller

- Line up side arms and push seat down until it clicks into place. Ensure that the backrest adjusting strap buckle is facing away from the handle.



### To Attach Raincover/Sunshade

- Place raincover / sunshade over front of hood.
- Zip raincover / sunshade onto hood.



### To Reverse Seat from MBB to MFB

- Press bottom silver buttons on both sides of stroller frame simultaneously and lift bassinet out. Turn seat around and place back onto frame.



### To Fold the Stroller

**Note:** This stroller can be folded with the stroller seat attached (MBB mode). For a more compact fold, the stroller seat can be removed from the stroller seat.

- Remove bassinet / seat, lock front swivels.
- Press lever on right hand safety lock of the upper handlebar. With the button held in, pull both handlebar trigger locks upwards. Gently push down handle.



### To Attach and Remove the Hood

- Push each end of the hood into the plastic holders located on either side of the seat frame.
- Attach press studs of hood onto stud on hood ratchet.
- To remove hood, squeeze small clips on both hood ends so hood can pull out through the plastic holders.



### To Attach Bumper Bar

- Slide each end of the bumper bar into the plastic holders located on either side of the seat frame.

**Warning:** Do not use the bumper bar as a carry handle.



### To adjust angle of seat

- Press top oval silver buttons on both sides of stroller frame simultaneously and adjust to desired angle.



### To Attach Bootcover

- Place bootcover over stroller and attach studs to the side of the hood.



- Place mattress into seat.
- Feed crotch strap through the bottom hole of the mattress, and pull through waist straps from side of mattress.
- The shoulder straps are to be placed under the mattress.

**Warning:** To avoid strangulation hazard, the over shoulder harness must be properly hidden beneath the mattress.



### To Attach and Remove the Hood

- Push each end of the hood into the plastic holders located on either side of the seat frame.
- Attach press studs of hood onto stud on hood ratchet.
- To remove hood, squeeze small clips on both hood ends so hood can pull out through the plastic holders.



### To Attach Bootcover

- Place bootcover over bassinet and attach studs to the side of the hood.



### To Attach Raincover/Sunshade

- Place raincover / sunshade over front of hood.
- Zip raincover / sunshade onto hood.



### STROLLER SUNSHADE

**Blocks up to 75% of harmful UV Rays**

This sunshade should not be used as a sole method of sun protection. Always use in conjunction with the appropriate sunscreen protection and ensure your child is appropriately clothed.

### To Remove Bassinet from Stroller

- Press bottom silver buttons on both sides of stroller frame simultaneously and lift bassinet out.



**WARNING: BASSINET CANNOT STAND ALONE**

## STROLLER MODE



**Warning:** Before converting into stroller mode the mattress **MUST** be removed and the full five point harness **MUST** be used at all times.

**Warning:** When seat is in the fully reclined position in stroller mode, the hood must be attached and fully secured at the back of the seat frame, as this will form a safety head barrier at the top of the seat.

### To convert into stroller

#### To Form Footrest

- Buckle strap up that is under the front of the bassinet.



#### To Form the Backrest

To lift seat upwards

- Hold the strap buckle in one hand and push buckle upwards

To lower seat

- Press buttons on strap buckle and pull down to desired position.

