

Jeep® Sports Series Rocker Instructions



Jeep



WARNING

Please take a moment to read through these instructions before you use your Jeep® Rocker.

Important Safety Information:

- Never leave your child unattended while in rocker.
- To prevent choking hazard, remove and discard all packing material before using this product.
- Always use restraint system to keep child from standing up or falling out of the rocker. Use the harness at all times.
- Only use this rocker with a child weighing less than 9 kg.
- Never use near edges of countertops, tables or other elevated surfaces.
- Do not allow children to stand on seat.
- The rocker should not be used near an open fire or exposed flame.
- Never use rocker as a car seat; it will not protect your baby during an accident.
- Do not allow strings to hang into rocker, including blind cords or suspended toys other than what is provided with this product.
- Do not use around pets or other children.
- Do not continue using infant rocker if it becomes bent, broken or if the cloth cover is ripped or torn.

REQUIRES ONE C SIZE BATTERY *(not included).*

Parts List



Rocker Frame



Toy Bar



Vibrator

How to Assemble Your Rocker

To Open Rocker

- 1** Remove any cardboard inserts, plastic bags or ties used to protect the product during shipment.

2



- 2** Rotate rocking bar around to back of Rocker until bar locks into place.

To Insert Batteries into Vibrator

1



1 Remove battery cover by removing the screw with a Phillips screwdriver.

2



2 Place battery as shown.

3 Replace battery cover and replace screw with Phillips screwdriver.

To Attach Vibrator

1




1 Insert vibrator into hole in fabric as shown and line up the vibrator with slots in base.



2 Push in until vibrator locks into place.

To Remove Vibrator

1



1 Push in lever as shown.

2 Pull out Vibrator.

To Attach Toy Bar

1



1 Take one end of Toy Bar and clip onto seat tube as shown.

2 Repeat for the other side.



How to Properly Use Your New Rocker

To Position Rocker

1



1 Turn the knobs on each side of the Rocker anti-clockwise to unlock.

2



2 Adjust the seat to the desired position by tilting the top of the seat.

3 Lock into place by turning both knobs clockwise.

To Stabilise Rocker

1





1 Turn feet away from rocking bar as shown until they both lock into place.





2 Turn both feet back into frame to make Rocker rock.

To Remove Seat Cover

- 1** Remove Vibrator (*see page 7*).
- 2**  Undo both press studs under the seat as shown.
- 3**  Pull cover over footrest first, then pull from top until cover comes off.
- 4** Reverse these steps to re-attach Seat Cover.

To Store Rocker

- 1** Turn Rocker on its side.
- 2**  Pull locking clip until it releases rocking bar.
- 3**  Rotate rocking bar around to the front of the rocker as shown.

Care & Maintenance

There are many ways to look after and protect your Jeep® rocker. The most important is to clean up any spills or food, before it dries on the fabric.

As the covers are not designed to be easily taken off for washing, (for safety reasons) the easiest method to clean is, sponge the surfaces with a mild solution of warm water liquid laundry detergent. Rinse well with clean sponge and leave to dry out of direct sun.

Sand and Salt water should be rinsed with a hose and wiped dry to prolong the life of the wheels, axles and other moving parts.

Never use petroleum based lubricants on your rocker, the most suitable lubricants are silicone based products.

Warranty

Jeep® is a registered trademark of DaimlerChrysler Corporation, and is used under license by Born With Style. ©DaimlerChrysler Corporation 2006.

Born With Style warrants this product to be free of defects in materials and workmanship as follows: For a period of ONE YEAR from the date of purchase, Born With Style will repair or replace, at its option, the defective product. This warranty is given in addition to (and not in substitute for) applicable statutory rights which you may have.

We sincerely thank you for purchasing this Born With Style product.

For further information visit: www.bornwithstyle.com.au

Contact Details

For all spare parts, repairs or warranty issues, please contact:

Karlisles

Phone: 1300 308 435

Email: info@karlisles.com.au

Web: www.karlisles.com.au

Replacement parts provided by local distributor due to accidental damage or misuse will be charged accordingly.

To contact the manufacturer directly:

Born With Style

PO Box 789

Gladesville NSW 1675, Australia

Phone: 1300 855 337 or 02 9816 3837

Email: info@bornwithstyle.com.au

Personal Record Card

Born With Style recommends that you keep a record of important information about your Jeep® rocker. Please complete the information in the space provided.

Model Number:

Date of Manufacture:

Date of Purchase:

