



Warranty

Each Steelcraft unit is thoroughly inspected in our Quality Assurance department prior to delivery. In the unlikely case that you find any material or workmanship that affects the units normal operation, we will repair the unit free of charge within 12 months of purchase. You are required to present your receipt as proof of purchase. For all concerns with your product please contact our Customer Service team.

CUSTOMER SERVICE
1300 303 330 - Australia
0508 688 822 - New Zealand

Please read all the information carefully before using this product. This warranty does not apply to failure due to improper care, or normal wear and tear caused by product use. We reserve the right to inspect the unit. You may be charged for repairs if the product has been damaged accidentally.

Distributed by:

AUSTRALIA
BRITAX CHILDCARE PTY.LTD.
A Britax International company.
(Incorporated in Victoria)
A.B.N. 55 006 773 600
99 Derby Road, Sunshine,
Victoria 3020, Australia
Phone: (03) 9288 7288
Fax: (03) 9311 5798

NEW ZEALAND
BRITAX CHILDCARE NZ. Limited.
A Britax International company.
101 Diana Drive, Glenfield,
Auckland 9, New Zealand.
Phone: (09) 443 0102
Fax: (09) 443 0120

Due to our continuing program of development, Britax reserves the right to alter the specifications, colour or design without any further notice.

The Steelcraft trademark is the property of Britax Childcare Pty. Ltd-Australia.
The Britax trademark is the property of Britax Excelsior Limited - UK.
Visit the Britax website at: <http://www.britax.com.au> or email us at custserv@britax.com.au

Due to the variations in the style and design of our products the illustrations used in this instruction booklet are generic.
12/06©2007 Copyright Britax Childcare Pty. Ltd. Australia.

INSTRUCTION MANUAL



3 in 1 Portable Cot

WARNING:

KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FURTHER REFERENCE.

BEFORE ASSEMBLING THIS COT READ & UNDERSTAND THESE INSTRUCTIONS. INCORRECT ASSEMBLY MAY MAKE THE COT UNSAFE

DO NOT USE THIS COT IF ANY PART IS BROKEN, TORN OR MISSING.

A MATTRESS IS SUPPLIED WITH THIS COT. NO OTHER MATTRESS SHOULD BE USED.



BEFORE ASSEMBLING THIS COT READ AND UNDERSTAND THE INSTRUCTIONS. INCORRECT ASSEMBLY MAY MAKE THE COT UNSAFE. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

WARNINGS

- Never leave your child unattended.
- Do not use your cot if any part is broken, torn or missing.
- Do not use or leave the cot near open fires, naked flames, electric bar fires, gas fires, stoves, heaters or barbecues.
- Do not place the cot where your child could reach medication, money, string, elastic, small toys or other small objects.
- Do not place the cot near trailing cords, leads or flexes such as cords or electrical leads, etc.
- Do not use additional mattress or padding.
- Do not place toys or other objects in the cot which could provide a step or foothold to help the child climb out.
- Cots with padded rails should not be used if the covered fabric is torn or bitten through.
- Do not use parts or accessories except those tested and approved by Britax.
- Always check that the folding parts are fully locked before using the cot.
- Do not place more than one child in the cot at the same time.
- Do not use this cot with a child who can climb out, weighs more than 15kg, or is taller than 90cms.
- When using a fitted sheet it must fit the mattress tightly.
- Check that the assembly of the cot is correct and safe.
- The thickness of the mattress has been specified to ensure that the distance from the top of the mattress to the top of the lowest side or end will always be at least 500mm. This will reduce the risk of children falling out of the cot.
- Always check parts regularly for tightness of screws, nuts and other fasteners - tighten if required.
- Use only the mattress supplied with the cot.
- Do not use an additional mattress, padding, toys or other objects in the cot which would help your child fall out.
- Using the wrong size mattress may create hazardous gaps that could result in suffocation or could reduce the side height of the cot, which may result in your child falling out of the cot.

NOTES

1. TO OPEN THE COT

THESE STEPS WILL ENSURE THAT THE COT IS CORRECTLY OPENED AND READY FOR USE.




- A Unzip the carry bag and remove the cot.
- B Stand the cot on its feet and undo the hook & loop straps that hold the mattress around the frame.
- C Remove the mattress and set it aside.
- D Separate the legs of the cot.
- E Starting with the short rails pull the centre up with both hands quickly until they are locked in place.

(CAUTION: TAKE CARE, AS FINGER PINCHING CAN OCCUR IN THE CORNERS WHEN LOCKING THE RAILS IN PLACE.)

- F Now do the same with the longer rails.

NOTE: ALL THE TOP RAILS SHOULD BE LOCKED IN PLACE. IF THEY ARE NOT, RELEASE THEM AND TRY AGAIN. THE CENTRE OF THE COT BASE MUST BE IN A RAISED POSITION TO ALLOW THE RAILS TO LOCK EASILY. CHECK FOR THE SECURE ENGAGEMENT OF THE RAILS BY PUSHING DOWN ON THEM.

- G Holding one end of the cot clear of the ground, gently press down on the handle in the middle of the base until the base lays down flat. Then turn the handle clockwise to lock the base in position and fold the handle down so it lies flat in the cot base.



CARE AND MAINTENANCE

To prolong the life of your nursery product keep it clean and do not leave it in the direct sunlight for extended periods of time.

Removable fabric covers and trims may be cleaned using warm water with a household soap or a mild detergent. Allow it to dry fully, preferably away from the direct sunlight.

DO NOT DRY CLEAN, OR USE BLEACH.

Do not machine wash, tumble or spin dry, unless the care labelling on the product permits these methods.

Non removable fabric covers and trims may be cleaned using a damp sponge with soap or mild detergent. Allow it to dry completely before folding or storing it away.

In some climates the covers and trims may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if it is damp or wet. Always store the product in a well ventilated area.

To maintain the safety of your nursery product, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories tested and approved by Britax.

WARNING: IF THE SIDES DO NOT LATCH FIRMLY OR THERE ARE HOLES IN THE MESH SIDES, DISCONTINUE USE IMMEDIATELY AND SEEK REPAIR.

TESTED AND APPROVED ACCESSORIES

Mattress by Steelcraft	- series S601L
Bassinet by Steelcraft	- series S601L
Change Table by Steelcraft	- series S601L

5. TO USE THE CHANGE TABLE

- A Lay the change table padded side down. Connect the straight rod (tube with 2 holes at each end) to one of the corner rods. With the corner rod curved upwards, push the straight rod into the sleeve of the change table by gathering the fabric until it protrudes out the opposite end.
- B Connect the remaining corner rod to the protruding end of the straight rod by engaging the locking pins.
- C Insert the keys into the corner mouldings of the cot and turn the keys in the direction shown to attach the change table to the cot.
- D Rotate the change table into position and attach press studs.
- E To fold away, flip the change table over the side of the cot.
- F The change table mat can be inserted and removed by releasing the child harness and valcro.



ALWAYS DETACH THE CHANGETABLE BEFORE FOLDING THE PORTABLE COT.

1. TO OPEN THE COT (con't)

- H Place the mattress into the cot with its padded side facing up.
- I Secure the mattress to the cot by passing the loop straps through the slot in the cot base and pressing it into the hook attachment strips, sewn to the underside of the cot base.



NOTE: ALWAYS SECURE THE MATTRESS BEFORE USING THE COT

2. TO USE THE WHEELS

- A Push the brake lever down to lock, or lift the brake lever up to unlock.

NOTE: ALWAYS APPLY THE BRAKES WHEREVER AND WHENEVER YOU ARE USING THE COT.
(Push down to lock) (Lift up to unlock)



3. TO FOLD THE COT


THESE STEPS MUST BE FOLLOWED IN THIS ORDER TO EASILY FOLD THE COT.

IF BASSINET OR CHANGE TABLE ARE FITTED, THEY MUST BE REMOVED BEFORE FOLDING THE COT.

- A Release the loop straps that secure the mattress and remove the mattress from the cot.

3. TO FOLD THE COT (con't)

- B Rotate the handle in the middle of the base anti-clockwise and then pull base up approximately 50cm.
- C Release each top rail by lifting the rail slightly and squeezing on the buttons, located under the centre joint. The buttons are covered by the top rail fabric and are located at the centre of each rail.



IF THE TOP RAILS DO NOT FOLD - DO NOT FORCE THEM - LIFT THE BASE HIGHER AND RE SQUEEZE THE BUTTONS TO FULLY RELEASE THEM.




- D Ensure that each rail is fully released and then pull up on the cot base handle, while gathering the legs and the frame together until its fully folded.

DISASSEMBLE AND STORE THE BASSINET AND CHANGE TABLE IN THE CARRY BAG.

- E Take the mattress and wrap it around the folded cot with the padded side facing inwards.
- F Thread the straps through the plastic loops, pull them tight and secure using the hook and loop attachments.
- G Take the carry bag and cover the folded cot. Finish covering the cot and close the zipper.

4. TO USE THE BASSINET

- A Insert the 2, two-piece support rods into bassinet inner sleeves separately, then engage them in the middle by the locking pin.
- B Insert the mattress and secure it to the bassinet by passing the loop straps through the slots in the bassinet base, then press the loop straps onto the hook padding, sewn to the underside of the bassinet.
- C Lower the bassinet into position within the cot frame.
- D Snap the eight plastic clips onto the top rails of the cot. Make sure the plastic clips are positioned against the edge of the corner mouldings.
- E Attach the "hook & loop" strips in each corner of the cot.



NOTE: ALWAYS SECURE THE MATTRESS BEFORE USING THE BASSINET.

WARNING: TO PREVENT FALLS, THIS BASSINET SHOULD NOT BE USED ONCE A CHILD CAN SIT UP.

ALWAYS REMOVE THE BASSINET BEFORE FOLDING THE PORTABLE COT.