

Spare Parts Diagram 105-713_Spare_Parts

2008 Breeze Buggy Anodised



ITEM NO.	PART NUMBER	DESCRIPTION
1	502-895-v2	Foam Handle Cover
2	203-893	Single Breeze Adj. Handle Sub Assy
5	203-744	Anodised Breeze RH base tube assy
6	203-743	Anodised Breeze LH base tube assy
7	203-746	Anodised Breeze RH down tube assy
8	203-745	Anodised Breeze LH down tube assy
9	203-507	Breeze link wire sub assy
10	203-377	Breeze seat frame sub assy
11	203-721	Anodised handle bottom tube assy
13	203-595	Breeze rear axle assy
14	309-968-3rd form	Single Acting Brake Wire (05.04.04)
18	503-876	Basket
19	309-009	Riserplate Pivot Tube (single)
20	503-915	Basket Clip
21	203-880-A	Screen Printed Foot Plate Riser
22	203-695	Secondary Lock LH Sub Assy
23	203-694	Locking slider RH Sub Assy
24	504-257-A	Footplate - plastic
25	504-707	10" Tyre and Tube
26	504-069	Break Cog (5 Lug)
27	504-547	Breeze QR rear wheel assembly (pneu)
28	504-398	Front Wheel Assembly (pneu)
30	504-102	Triloc Knob
31	503-917	Single Front Axle Shaft
32	504-937-A	Brake Wire Cover

