

Spare Parts Diagram 105-712_Spare_Parts
2008 Double Terrain 2008



ITEM NO.	PART NUMBER	DESCRIPTION
1	504-472-fixed-ter	Foam Handle Cover
2	203-739	Anodised handle frame assy - Terrain dbl rec
5	203-738	Anodised base tube assy RH - Terrain dbl
6	203-737	Anodised base tube assy LH - Terrain dbl
7	203-351	Suspension down tube assy RH - Terrain dbl
8	203-350	Suspension down tube assy LH - Terrain dbl
9	203-585	Terrain seat link wire - sub assy
10	203-356	Seat frame assy - Terrain dbl
11	203-721	Anodised handle bottom tube assy
12	203-584	Terrain tracking tensioner - set
13	203-594	Double Terrain Rear Axle Assy
14	309-966-3rd form-rev01	Double Urban Brake Wire
15	308-928	Front Spacer Tube - dbl terrain
16	504-551-A	Riserplate & axle clamp
17	203-606	Terrain rec Hammock support intermediate assy
18	104-117	Double Wire Basket
19	308-946	Riserplate Pivot Tube (double)
20	503-915	Basket Clip
21	203-881-A	Footplate Riser
22	203-695	Secondary Lock LH Sub Assy
23	203-694	Locking slider RH Sub Assy
24	203-763	Anodised Double Footrest Sub Assy
25	504-075	12" Tyre and Tube
26	504-021	Break Cog (6 Lug)
27	504-442	Q.R. rear wheel assy - STD tyre
28	504-075	12" Tyre & rim assy (STD tread)
29	310-306	Front Axle Bush Tube - PAINTED
30	504-102	Triloc Knob
31	503-921	Front Axle Shaft - double
32	504-937-A	Brake Wire Cover

