

Spare Parts Diagram 105-712_Spare_Parts
2008 Double Terrain 2008



ITEM NO.	DESCRIPTION
1	Foam Handle Cover
2	Anodised handle frame assy - Terrain dbl rec
5	Anodised base tube assy RH - Terrain dbl
6	Anodised base tube assy LH - Terrain dbl
7	Suspension down tube assy RH - Terrain dbl
8	Suspension down tube assy LH - Terrain dbl
9	Terrain seat link wire - sub assy
10	Seat frame assy - Terrain dbl
11	Anodised handle bottom tube assy
12	Terrain tracking fensioner - set
13	Double Terrain Rear Axle Assy
14	Double Urban Brake Wire
15	Front Spacer Tube - dbl terrain
16	Riserplate & axle clamp
17	Terrain rec Hammock support intermediate assy
18	Double Wire Basket
19	Riserplate Pivot Tube (double)
20	Basket Clip
21	Footplate Riser
22	Secondary Lock LH Sub Assy
23	Locking slider RH Sub Assy
24	Anodised Double Footrest Sub Assy
25	12" Tyre and Tube
26	Break Cog (6 Lug)
27	Q.R. rear wheel assy - STD tyre
28	12" Tyre & rim assy (STD tread)
29	Front Axle Bush Tube - PAINTED
30	Triloc Knob
31	Front Axle Shaft - double
32	Brake Wire Cover

