

Spare Parts Diagram 105-711\_Spare\_Parts  
**2008 Single Terrain 2008**



ITEM NO.	DESCRIPTION
1	Foam Handle Cover
2	Anodised Sgl Terrain Handle Assy
5	Anodised base tube assy RH - Terrain sgl
6	Anodised base tube assy LH - Terrain sgl
7	Terrain Sgl RH Suspension Down Tube Assy
8	Terrain Sg lSuspension Down Tube Assy LH
9	Terrain seat link wire - sub assy
10	Seat frame assy - Terrain sgl
11	Anodised handle bottom tube assy
12	Terrain tracking tensioner - set
13	Terrain single rear axle assy
14	Single Acting Brake Wire (31.07.06)
18	Wire Basket
19	Riserplate Pivot Tube (single)
20	Basket Clip
21	Screen Printed Foot Plate Riser
22	Secondary Lock LH Sub Assy
23	Locking slider RH Sub Assy
24	Anodised single footrest - (mid 2006)
25	12" Tyre and Tube (Slash Tread)
26	Break Cog (6 lug)
27	Q.R. rear wheel assy - STD tyre
28	12" Tyre & rim assy (STD tread)
29	Front Axle Bush Tube - PAINTED
30	Triloc Knob
31	Single Front Axle Shaft
32	Brake Wire Cover

